


SHG10の基本操作を覚える

SHG10のディスプレイはタッチパネルです。指でディスプレイをタップすることで、いろいろな操作が行えます。ジェスチャーナビゲーションの操作について覚えましょう。



AQUOS Homeの操作



MEMO **メニューアイコン**

一部の画面では画面右上にメニューアイコン：  が表示されます。メニューアイコンをタップすると、アプリごとに固有のメニューが表示されます。



ジェスチャーナビゲーションの操作方法

画面を左端から右方向にスワイプすると直前に操作していた画面に戻ります。メニューやステータスパネルなどを閉じることもできます。

アプリを起動した状態で画面下部を上方向にスワイプするとホーム画面が表示されます。ホーム画面で上方向にドラッグすると最近使用したアプリが一覧表示され、アプリの終了や切り替えが行えます（P.21参照）。

タッチパネルの操作

タップ/ダブルタップ

タッチパネルに軽く触れてすぐに指を離すことを「タップ」といいます。同じ位置を2回連続でタップすることを、「ダブルタップ」といいます。



ロングタッチ

アイコンやメニューなどに長く触れた状態を保つことを「ロングタッチ」といいます。



ピンチアウト/ピンチイン

2本の指をタッチパネルに触れたまま指を開くことを「ピンチアウト」、閉じることを「ピンチイン」といいます。



スワイプ(スライド)

画面内に表示しきれない場合など、タッチパネルに軽く触れたまま特定の方向へなぞることを「スワイプ」または「スライド」といいます。



フリック


タッチパネル上を指ではらうように操作することを「フリック」といいます。



ドラッグ

アイコンやバーに触れたまま、特定の位置までなぞって指を離すことを「ドラッグ」といいます。






Handwritten text in a non-Latin script, including 'Zmub' and 'btif xzp \{b'.

Handwritten text in a non-Latin script, including 'b' and 'Ó'.


Handwritten text in a non-Latin script, including 'b'.




Handwritten text in a non-Latin script, including 'b'.



Handwritten text in a non-Latin script, including 'b' and 'Ó'.



Handwritten text in a non-Latin script, including 'b' and 'Ó'.



Handwritten text in a non-Latin script, including 'b' and 'Ó'.

